General Description

The grease pump is used for dispensing preset quantity of grease into various machine components such as bearings, shaft assemblies, gear assemblies etc.

Sequence of operation

- (i) Press Foot Switch momentarily. Sol1 is switched 'ON', causing air to flow into port 'A' and exhaust from port 'B'.
- (ii) The pump discharges grease at high pressure through nozzle. The quantity of dispensed grease can be varied by adjusting knob.
- (iii) At the end of the dispensing stroke, limit switch LS1 is actuated, causing Sol2 to come 'ON'. The dispenser returns back to original position.
- (iv) The Grease Reservoir can be fitted automatically from a 200kg drum through a barrel transfer pump connected to grease inlet port on the barrel. The low and high level of grease in the barrel is sensed by reed switches RS1 & RS2 which switch solenoid valve feeding air to the barrel transfer 'ON' & 'OFF'.



